

Garmin GPSmap 60CSx Field Cheat Sheet

Using the GPSMAP 60Cx Keypad

POWER key

- Press and hold to turn the unit on or off.
- Press and release to adjust the backlighting.

IN/OUT Zoom Keys

- Press to zoom in or out on the Map Page.
- Press to scroll up or down a list on any other page.

FIND/MOB key

- Press and release at any time to view the Find Menu.
- Press and hold for MOB*

MARK key

- Press and release at any time to mark your current location.

QUIT key

- Press and release to cancel data entry, or exit a page.

ROCKER key

- Press up, down, left, or right to highlight options; and to enter data, or move the map panning arrow.

PAGE key

- Press and release to cycle through the main pages.

MENU key

- Press and release to view page options.
- Press twice to view the Main Menu.

ENTER key

- Press and release to enter highlighted options, data, or confirm on-screen messages.


* Man Overboard (MOB) feature stores a waypoint and then navigates back to it.

GPSMAP 60Cx Owner's Manual

3

Creating waypoints:


1. Use the **MARK** key to quickly capture your location
2. Using the directional rocker to navigate the screen...
 - a. Change the default waypoint name to something more memorable (remember, the default is a three-digit number).
 - i. **Navigate** the waypoint name field and press **ENTER**.
 - ii. Use the rocker to select a combination of letters/numbers for your waypoint name.
 - iii. Press **ENTER** for each letter/number you want to select.
 - iv. When you're done, navigate to **OK** in the center of the screen and press **ENTER**.



- b. You can also add notes in the same way.
- 3. When you are done, navigate to the **OK** button in the bottom **RIGHT** of the screen and press **ENTER** (see below).

Creating tracks:

- 1. To set up a track log...
 - a. Press **MENU** twice
 - b. Select **TRACKS** icon and press **ENTER**
 - c. Select **SETUP** and press **ENTER**
 - d. Select the following options:
 - i. Record method = **TIME**
 - ii. Interval = **15 seconds**
 - iii. Color = your preference
 - iv. Press **QUIT** to return to previous page.



- 2. To save a track log...
 - a. Press **MENU** twice
 - b. Select **TRACKS** icon and press **ENTER**
 - c. Select **SAVE** and press **ENTER**
 - d. Select **YES** and press **ENTER** to save the entire track
 - e. Rename your track if necessary